



3J Driveline Peugeot MA LSD

Important information when re-fitting your plate type MA LSD endplate.

- Make sure the Crown Wheel has been machined/modified to drawing provided before fitting.
- Please make sure all x 6 Dowels are secure and in the Diff housing/ CW.
- Align with endplate dowel pockets
- Use a slither of Loctite and fasten Endplate bolts to 35-40 lbs/ft